




# Senstar E5000 Physical Security Appliance User Guide




# Contents

---


Introduction.....	3
In the box.....	3
Specifications.....	4
Safety, maintenance, and support information.....	4
Default credentials.....	5
Input and output connections.....	5
COM pinout.....	5
LAN pinout.....	7
Installation.....	8
Mount the Senstar Physical Security Appliance (optional).....	8
Connecting to your network.....	8
Legal information.....	10

# Introduction

The Senstar Physical Security Appliance combines a purpose-built hardware appliance with the Senstar Symphony video management and analytics software, creating a high-performance, intelligent video surveillance platform.



The robust, fanless design and flexible installation options of the Senstar Physical Security Appliance make it an ideal solution for space-constrained and harsh environments.



## In the box

Your Senstar E5000 Physical Security Appliance package includes the following items:

- Senstar E5000 Physical Security Appliance
- Brackets and hardware for wall mount
- Power adapter and cord

## Specifications

	E5004-8A	E5004-16A
OS	Windows 10 IOT Enterprise	Windows 10 IOT Enterprise
Internal storage	4 TB	4 TB
Camera licenses	8	16
Ethernet	4xGbE	4xGbE
USB	8	8
Inputs/outputs	8	8
Monitor output	HDMI (x2)	HDMI (x2)
Network protocols	<ul style="list-style-type: none"> <li>• DHCP</li> <li>• SMTP</li> <li>• SNMP</li> </ul>	<ul style="list-style-type: none"> <li>• DHCP</li> <li>• SMTP</li> <li>• SNMP</li> </ul>
Operating temperature	-20 to 55 ° C	-20 to 55 ° C
Input voltage	10 to 35 VDC	10 to 35 VDC
Compliance	<ul style="list-style-type: none"> <li>• CE</li> <li>• FCC</li> <li>• RoHs</li> </ul>	<ul style="list-style-type: none"> <li>• CE</li> <li>• FCC</li> <li>• RoHs</li> </ul>
Mounting kit	Wall mount included	Wall mount included
Warranty	3 year	3 year

## Safety, maintenance, and support information

Review the following information before installing the Senstar E5000 Physical Security Appliance:

Item	Instruction
Power source	Use the included AC/DC power supply adapter to power the 10-35 Vdc input required.
Heat	Do not use the Senstar E5000 Physical Security Appliance in an area that contains heat sources.
Water/moisture	Do not use the Senstar E5000 Physical Security Appliance in an area where it might come in contact with liquid. Do not spill liquid on the Senstar E5000 Physical Security Appliance. When moving the Senstar E5000 Physical Security Appliance to an area with a significant temperature difference, do not plug in the Senstar E5000 Physical Security Appliance immediately—allow the Senstar E5000 Physical Security Appliance to adjust to the new temperature for at least two hours.
Cleaning	Unplug the Senstar E5000 Physical Security Appliance before cleaning. Use a dry microfiber cloth to wipe the Senstar E5000 Physical Security Appliance clean. Do not use water or chemical cleaners to clean the Senstar E5000 Physical Security Appliance.

Item	Instruction
Damage/hardware failure/missing parts/service	In the event of a hardware failure, contact Senstar support to obtain a Return Material Authorization (RMA) number. Senstar cannot guarantee that it will ship a new replacement unit against an RMA. Senstar may replace the Senstar Physical Security Appliance with a refurbished Senstar Physical Security Appliance or substitute a similar product.
Warranty	Obtain your warranty statements and license agreements for hardware and software at <a href="https://senstar.com/support/warranty/">https://senstar.com/support/warranty/</a> .

## Default credentials

Use the following credentials to log in to Senstar Physical Security Appliance and the Senstar Symphony Server configuration interface.


Interface	Default credentials
Windows operating system	Username: Admin Password: SenstarPSA
Senstar Symphony	Username: Admin Password: Admin

## Input and output connections

The Senstar Physical Security Appliance includes a 10-pin connector on the back of the device with 8 DIO pins, a GND pin, and a 5V pin.


To use the DIO pins, you must use the Universal Configuration Manager (UCM) to configure the pins to act as either an input or an output. Once you configure the pins, you can connect the pins to appropriate external devices.

The 8 DIO pins are 5V DC tolerant, ESD protected, and capable of sinking/sourcing a maximum of 12mA.



## COM pinout

The Senstar Physical Security Appliance includes 2 COM ports on the back of the device.




**Top port**

Pin	RS232	RS422	RS485
1	DCD	TX-	D-
2	RX	TX+	D+
3	TX	RX+	NC
4	DTR	RX-	NC
5	GND	NC	NC
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC

**Bottom port**

Pin	RS232	RS422	RS485
1	DCD	TX-	D-
2	RX	TX+	D+
3	TX	RX+	NC
4	DTR	RX-	NC
5	GND	NC	NC
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC

## LAN pinout



Pin	Signal	Signal type
1	MDI0+	DIFF
2	MDI0-	DIFF
3	MDI1+	DIFF
4	MDI2+	DIFF
5	MDI2-	DIFF
6	MDI1-	DIFF
7	MDI3+	DIFF
8	MDI3-	DIFF

# Installation

The Senstar Physical Security Appliance offers flexible installation options.


To install the Senstar Physical Security Appliance, complete the following workflow:

1. (Optional) Mount the Senstar Physical Security Appliance using the included wall mounts.
2. Use the default Ethernet port configuration information to choose which Ethernet port to use and connect the Senstar Physical Security Appliance to the network.
3. Connect power and turn on the Senstar Physical Security Appliance.
  - To access BIOS, press <DEL> or <F2> when the Senstar Physical Security Appliance is powering on.
  - To access boot options, press <F7> when the Senstar Physical Security Appliance is powering on.
4. (Optional) Perform additional configuration tasks for the Senstar Physical Security Appliance.

## Mount the Senstar Physical Security Appliance (optional)

1. With the Senstar Physical Security Appliance on a flat surface, turn it upside down.
2. Place the metal wall mounts flush with the Senstar Physical Security Appliance so that the side of the mounts with two holes lines up with the holes on the back of Senstar Physical Security Appliance.

Use the side of the brackets with holes to attach the Senstar Physical Security Appliance to the wall.




3. Use the small screws with the integrated spring washers and flat washers to fasten the mounts to the Senstar Physical Security Appliance.
4. Place the Senstar Physical Security Appliance on the wall and mark the location of the mounting holes with a pencil.
5. (Optional) Drill the holes for the wall anchors.
6. (Optional) Insert the anchors into the wall.
7. Insert the mounting screws loosely.
8. Place the wall mounts on the mounting screws.
9. Verify that the location is appropriate for the Senstar Physical Security Appliance.
10. Tighten the mounting screws.

## Connecting to your network


The Senstar E-Series Server includes four Ethernet ports to support connections to multiple networks. Do not connect the Ethernet ports to the same network.

The Senstar E-Series Server can connect to a single network that includes cameras and client computers.





The Senstar E-Series Server can connect to multiple networks and act as a DHCP server for one of the networks. These features allows you to isolate the video devices from a corporate network. In this case, video footage traverses the corporate network only if a user requests it. Do not connect multiple network ports to the same network.



Ethernet port	Configuration
LAN1-4	<ul style="list-style-type: none"> <li>• The Senstar E-Series Server obtains an IP address automatically from the DHCP server on the network.</li> <li>• If a DHCP server is not available, the Senstar E-Series Server uses automatic private IP addressing to set the IP address to 169.254.x.y (where x.y is the unique identifier of the Senstar E-Series Server) with a subnet of 255.255.0.0.</li> </ul>

## Legal information

---

Copyright © 2023 Senstar Corporation and/or its Licensor(s). All rights reserved.

This material is for informational purposes only. Senstar makes no warranties, express, implied or statutory, as to the information in this document.

Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Senstar Corporation

Senstar may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Senstar, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

Senstar and the Senstar logo are registered trademarks of Senstar Corporation.

All other trademarks are the property of their respective owners.